

Installation and Maintenance Manual

WorldWide Electric Corporation - "Original" Series Shaft Mount Reducer

Contents

Installation	3
Lubrication Schedule	5
Replacement of Parts	6
Motor Mount Installation	9
Backstop Installation	10
Backstop Description	10
Prior to Installation	10
Installation.....	11
After Installation.....	11
Dismantling	11
Lubrication and Maintenance of the Backstop Assembly.....	12
Backstop Assembly Type and Rotation Illustration	12
Backstop Dimensions	13
Guidelines for Long-term Storage	15
SMR Exploded View.....	16
SMR Ratio/ Speed Table	17
Limited Warranty	17

WARNING: Because of the possible danger to person(s) or property from accidents which may result from improper use of products, it is important that correct procedures be followed. Products must be used in accordance with the engineering information specified in the WorldWide Electric Corporation Gear Reducers Stock Products catalog. Proper installation, maintenance and operation procedures must be observed. The instructions in this installation and maintenance manual must be followed. Inspections should be made as necessary to assure safe operation under prevailing conditions. Proper guards and other suitable safety devices or procedures, as may be desirable, or as may be specified in safety codes should be provided, and are neither provided by WorldWide Electric Corporation, nor the responsibility of WorldWide Electric Corporation. This unit and its associated equipment must be installed, adjusted and maintained by qualified personnel who are familiar with the construction and operation of all equipment in the system and the potential hazards involved. When risks to persons or property may be involved, a holding device must be an integral part of the driven equipment beyond the speed reducer output shaft.




Installation

Note: Satisfactory performance depends on proper installation, lubrication and maintenance. Therefore, it is important that the instructions in this manual are followed carefully.

1. Use eyebolts or lifting lugs to lift reducer.
2. Determine the running positions of the reducer (see Figure 1). **Note:** The reducer is supplied with four plugs around the sides and one on each face for vertical installations. These plugs must be arranged relative to the horizontal running positions as follows: the bottom one is the drain plug (D). Install the breather plug (B) in the topmost hole. Of the three remaining plugs on the sides of the reducer, the lowest one is the minimum oil level plug (L).

The running position of the reducer is not limited to the six positions shown in Figure 1. However, if running position is over 20 degrees in position (B) and (D) or in 5 degrees in position (A) or (C) either way from sketches, the oil level plug cannot be used safely to check the oil level, unless during the checking, the torque arm is disconnected and the reducer is swung to within 20 degrees for position (B) and (D) or 5 degrees for position (A) or (C).

Figure 1- Mounting Positions



Note: Below 15 RPM output speed, oil level must be adjusted to reach the highest oil level plug (P).

Because of the many possible positions of the reducer, it may be necessary or desirable to make special adaptations using the lubrication filling holes furnished along with other standard pipe fittings, stand pipes and oil level gauges as required.

3. Mount reducer on driven shaft as follows:

WARNING: To ensure that the drive is not unexpectedly started, turn off and lock out or tag the power source before proceeding. Remove all external loads from drive before removing or servicing reducer or accessories. Failure to observe these precautions could result in bodily injury.





Figure 3.




Belt drive may be located in any convenient position. If the torque arm is to be used to tighten the belts, the drive should be at about 90 degrees to the line between the input and output shafts.

Belt drive may be located to the right if desired.

5. Install motor and wedge belt drive with the belt pulley at approximately 90 degrees to the center line between driven and input shafts (see Figure 3). This will permit tensioning of the wedge belt drive with the torque arm which should preferably be in tension. If output hub runs counter-clockwise, torque arm should be positioned to the right (see Figure 4).


Figure 4.



If the output hub rotates clock-wise, relocate the belt drive and torque arm in opposite direction to that shown in the illustration.

6. Install torque arm fulcrum on a rigid support so that the torque arm will be at approximately 90 degrees to the center line through the driven shaft and the torque arm case bolt (see Figure 5). If output hub rotates clock-wise, belt drive and torque arm in opposite direction to that shown in the illustration.

Figure 5.



Torque arm and belt may vary up to a take-up.

This angle should be a right angle, but may vary up to a maximum of 30 degrees either way.

Torque arm may be mounted to the right if desired.

CAUTION: All WorldWide shaft mount reducers are shipped without oil. Every WorldWide shaft mount reducer must be filled with a recommended gear oil. Failure to observe these precautions could result in damage to or destruction of the equipment. Failure to lubricate the shaft mount reducer will void the manufacturer's warranty.

CAUTION: Failure to install the breather plug may result in gearbox overheating and will prematurely cause the oil seals to leak. Failure to install the breather plug in the shaft mount reducer will void the manufacturer's warranty.

Lubrication Schedule

CAUTION: All WorldWide shaft mount reducers are shipped without oil. Every WorldWide shaft mount reducer must be filled with a recommended gear oil. Failure to observe these precautions could result in damage or destruction of the equipment. Failure to lubricate the shaft mount reducer will void the manufacturer's warranty.


CAUTION: Too much oil will cause overheating and too little will result in gear failure. Check oil level regularly. More frequent oil changes are recommended when operating continuously, at high temperatures or under conditions of extreme dirt or dust.

Model Number	15° To 60°F (-9° To 16°C)		50° To 125°F (10° To 50°C)	
Mobil	Mobil SHC 629	Mobil SHC 630	Mobil SHC 630	Mobil SHC 632
AGMA Rating	4	5	5	6
ISO Grade	150	220	220	320
SMR2	N/A	1-400 RPM	N/A	1-400 RPM
SMR3	151-400 RPM	1-150 RPM	151-400 RPM	1-150 RPM
SMR4	128-400 RPM	1-125 RPM	128-400 RPM	1-125 RPM
SMR5	101-400 RPM	1-100 RPM	101-400 RPM	1-100 RPM
SMR6	41-400 RPM	1-40 RPM	41-400 RPM	1-40 RPM
SMR7	41-400 RPM	1-40 RPM	41-400 RPM	1-40 RPM
SMR8	41-400 RPM	1-40 RPM	41-400 RPM	1-40 RPM
SMR9	41-400 RPM	1-40 RPM	41-400 RPM	1-40 RPM
SMR10	41-400 RPM	1-40 RPM	41-400 RPM	1-40 RPM


For Best Results

1. Fill with recommended gear oil and operate for two weeks.
2. Drain after two weeks and flush with light oil.
3. Wipe any metal shavings from the magnetic drain plug and re-install.
4. Refill with recommended gear oil and continue.
5. Repeat every 2,500 hours to maximize unit life.

Horizontal Applications



Vertical Applications



Model Number	Approximate Capacity (Quarts & Liters)					
	A	B	C	D	E	F
SMR2	0.875 Quarts	1.0 Quarts	0.625 Quarts	1.0 Quarts	1.625 Quarts	1.75 Quarts
	0.83 Liters	0.95 Liters	0.59 Liters	0.95 Liters	1.54 Liters	1.66 Liters
SMR3	1.5 Quarts	1.5 Quarts	0.75 Quarts	2.25 Quarts	2.625 Quarts	3.0 Quarts
	1.42 Liters	1.42 Liters	0.71 Liters	2.13 Liters	2.48 Liters	2.84 Liters
SMR4	1.875 Quarts	2.25 Quarts	1.25 Quarts	1.75 Quarts	3.375 Quarts	4.25 Quarts
	1.77 Liters	2.13 Liters	1.18 Liters	1.66 Liters	3.19 Liters	4.02 Liters
SMR5	3.25 Quarts	4.0 Quarts	3.25 Quarts	4.0 Quarts	7.0 Quarts	8.625 Quarts
	3.08 Liters	3.79 Liters	3.08 Liters	3.79 Liters	6.62 Liters	8.04 Liters
SMR6	4.25 Quarts	5.0 Quarts	4.25 Quarts	5.0 Quarts	8.625 Quarts	9.125 Quarts
	4.0 Liters	4.7 Liters	4.0 Liters	4.7 Liters	8.2 Liters	8.6 Liters
SMR7	6.5 Quarts	8.0 Quarts	7.25 Quarts	9.25 Quarts	15.375 Quarts	16.375 Quarts
	6.1 Liters	7.57 Liters	6.86 Liters	8.75 Liters	14.55 Liters	15.5 Liters
SMR8	8.5 Quarts	11.0 Quarts	10.5 Quarts	8.5 Quarts	19.125 Quarts	19.125 Quarts
	8.0 Liters	10.4 Liters	9.94 Liters	8.0 Liters	18.1 Liters	18.1 Liters
SMR9	13.0 Quarts	13.0 Quarts	12.5 Quarts	14.25 Quarts	25.375 Quarts	25.375 Quarts
	12.3 Liters	12.3 Liters	11.83 Liters	13.48 Liters	24.0 Liters	24.0 Liters
SMR10	23.0 Quarts	14.0 Quarts	15.75 Quarts	18.75 Quarts	41.0 Quarts	41.0 Quarts
	21.8 Liters	13.2 Liters	14.9 Liters	17.7 Liters	38.8 Liters	38.8 Liters

Replacement of Parts

Important: Using tools normally found in a maintenance department, shaft mount reducers can be disassembled and re-assembled by careful attention to the instructions following. Cleanliness is very important to prevent the introduction of dirt into the bearings and other parts of the reducer. A tank of clean solvent, an arbor press, and equipment for heating bearings and gears (for shrinking these parts on shafts) should be available. The oil seals are of the rubbing type and considerable care should be used during disassembly and re-assembly to avoid damage to the surface which the seals rub on. The key-seat in the input shaft, as well as any sharp edges on the output hub should be covered with tape or paper before disassembly or re-assembly. Also, be careful to remove any burrs or nicks on surfaces of the input shaft or out hub before disassembly or re-assembly.

Ordering Parts: When ordering parts for reducer, specify reducer size number, part name, part number, and quantity. It is strongly recommended that, when a pinion or gear is replaced, the mating pinion or gear is replaced also. If the large gear on the output hub must be replaced, it is recommended that an output hub assembly of a gear assembly on a hub be ordered to secure undamaged surfaces on the output hub where the output seals rub. However, if it is desired to use the old output hub press the gear and bearing off and examine the rubbing surface under the oil seal carefully for possible scratching or other damage resulting from the pressing operation. To prevent oil leakage at the shaft oil seals, the smooth surface of the output hub must not be damaged. If any parts must be pressed from a shaft or from the output hub, this should be done before ordering parts to make sure that none of the bearings or other parts are damaged in removal. Do not press against outer race of any bearing. Because old shaft rubber oil seals may be damaged in disassembly, it is advisable to order replacements for these parts.

REMOVING REDUCER FROM SHAFT

WARNING: To ensure that drive is not unexpectedly started, turn off and lock out or tag power source before proceeding. Failure to observe these precautions could result in bodily harm.

CAUTION: Remove oil external loads from drive before removing or servicing drive or accessories.

1. Remove bushing screws.
2. Place the screws in the threaded holes provided in the bushing flanges. Tighten the screws alternately and evenly until the bushings are free on the shaft. For ease of tightening screws, make sure screw threads and threaded holes in bushing flanges are clean.

DISASSEMBLY

1. Position the reducer on its side and remove all housing bolts. Drive dowel pins from housing. Gently tap the output hub and input shaft with a soft hammer (rawhide, not a lead hammer) to separate the housing halves. Open housing evenly to prevent damage to the parts inside.
2. Lift shaft gear, and bearing assemblies from housing.
3. Remove seals from housing.

RE-ASSEMBLY

1. Output Hub Assembly: Heat gear to 160- 180 degrees to shrink onto hub. Heat bearings to 130- 145 degrees to shrink onto hub. Any injury to hub surfaces where the oil seals rub will cause leakage, making it necessary to use a new hub.
2. Counter shaft Assembly: Shaft and pinion are integral. Press gear and bearings on shaft. Press against inner (not outer) race of bearing.



3. Input Shaft Assembly: Shaft and pinion are integral. Press bearings on shaft. Press against inner (not outer) race of bearings (for SMR2 press against the ball bearing on shaft).
4. Drive the two dowel pins into place in the right- hand housing half. Apply sealant to carriers for R. H. side (back stop side) of reducer. Install carriers and torque bolts with 30-27 foot-pounds for SMR3 to 6, 50-45 foot-pounds for SMR7 to 10. SMR2's do not have these carriers.
5. Place R. H. housing half on block to allow for protruding end of output hub.
6. Install bearing cups in right- hand housing half, making sure they are properly sealed (SMR2's do not have this step).
7. Mesh output hub gear and small counter shaft gear together and set in place in housing. Make sure bearing rollers (cones) are properly seated in their cups. Set bearing cups for left- handed housing half in place on their rollers (except SMR2).
8. Clean housing flange surfaces on both halves, making sure not to nick or scratch the face. Apply sealant to flange face (make sure that the sealant is placed between bolt holes and inside of the surface). Place L.H. housing into position and tap with a soft hammer (rawhide, not lead hammer) until housing bolts can be used to draw housing halves together. Torque housing bolts per torque values 30- 27 foot-pounds for SMR2, 50- 45 foot-pounds for SMR3 to 4, 75-68 foot-pounds for SMR5 to 6, 150- 135 foot-pounds for SMR7 to 10.
9. Place output hub seal carrier into position without shims and install two carrier screws diametrically opposed. Torque each screw to 25 inch-pounds. Rotate the output hub to roll in the bearings and then torque each screw to 50 inch-pounds. Again turn output hub to roll in the bearings. With a shim thickness, take the average of the two feeler gauge readings. Remove carrier and install the required shims plus 0.002". Install carrier with shims and torque bolts per torque values 17- 15 foot-pounds for SMR3, 30- 27 foot-pounds for SMR4 to 6, and 50- 45 foot-pounds for SMR7- 10. The SMR2 does not require this step. Rotate hub assembly, tap lightly with rawhide mallet on end of hub, while rotating, to ensure bearings are sealed. Using a dial indicator check end play of hub bearings, end play should be 0.001- 0.003. Repeat this process as necessary to obtain proper end play. Place sealant inside the carrier at the shim I.D. and install carrier on reducer housing. Torque carrier bolts to value 17- 15 foot-pounds for SMR3, 30- 27 foot-pounds for SMR4 to 6, and 50- 45 foot-pounds for SMR7 to 10. The SMR2 does not require this step.
10. Adjust the counter shaft bearings using the same method as in step 9 above. The axial end play should be 0.001" to 0.003".
11. Again, using the same procedure as in step 9, adjust the input shaft bearing, except the axial end play should be 0.002" to 0.004". Using gaskets install input shaft cover and counter shaft cover to right- handed housing half. Install input and output seals. Extreme care should be used when installing seals to avoid damage due to contact with sharp edges on the input shaft or output hub. The possibility of damage and consequent oil leakage can be decreased by covering all sharp edges with tape prior to seal installation. Fill cavity between seal lips with grease. Seals should be pressed or tapped with soft hammer evenly into place in the carrier, applying pressure only on the outer edge of the seals. A slight oil leakage the seals may be evident during initial running, but should disappear unless seals have been damaged.
12. Install bushing backup plates and snap rings on Taper Bushing reducers. (Please note SMR6, 8, 9's snap rings have a little notch for the bushing screw, and the notch must have a right angle to output hub's key seat.)
13. Install the backstop into the housing (please take attention to the rotation of the output hub's key seat.)
14. Install the backstop cover onto the box, if the cover was wrought iron, do not forget the backstop gasket, if the cover was cast iron, do not forget to place some sealant to the joint surface (inside the bolt holes).

Replacement Parts – SMR “Original” series Shaft Mount Reducers

Table 1 - Bearings for SMR “Original” series Shaft Mount Reducers (bearing type and dimensions inner *outer* width). The SMR2 shaft mount reducer has a ball bearing. SMR3 to SMR10 shaft mount reducers have roller bearings.

Model Number	Bearing Position					
	Input Shaft Input Side	Input Shaft Output Side	Intermediate Shaft Input Side	Intermediate Shaft Output Side	Output Hub Input Side	Output Hub Output Side
SMR2	6206 30*62*16	6305NR 25*62*17	6305 25*62*17	6305 25*62*17	6013 65*100*18	6013 65*100*18
SMR3	LM48548A/LM48510 34.925*65.088*18.034	15102/15245 25.4*62*19.05	15102/15245 25.4*62*19.05	15102/15245 25.4*62*19.05	LM814849/LM81410 77.788*117.475*25.4	LM814849/LM81410 77.788*117.475*25.4
SMR4	32208J 40*80*24.75	30306J 30*72*20.75	32206J 30*62*21.25	32206J 30*62*21.25	32017XJ 85*130*29	32017XJ 85*130*29
SMR5	32210J 50*90*24.75	30308J 40*90*25.25	32208J 40*80*24.75	32208J 40*80*24.75	32019XJ 95*145*32	32019XJ 95*145*32
SMR6	32212J 60*110*29.75	30310J 50*110*29.25	32309J 45*100*38.25	33209J 45*85*32	32022XJ 110*170*38	32022XJ 110*170*38
SMR7	33113J 65*110*34	30310J 50*110*29.25	32309J 45*100*38.25	32309J 45*100*38.25	32024XJ 120*180*38	32024XJ 120*180*38
SMR8	32214J 70*125*33.25	30312J 60*130*33.5	33213J 65*120*41	32212J 60*110*29.75	32928 140*190*32	32928 140*190*32
SMR9	32313J 65*140*51	30313J 65*140*36	30314J 70*150*38	30314J 70*150*38	32934 170*230*38	32934 170*230*38
SMR10	32314J 70*150*54	30314J 70*150*38	33217J 85*150*49	33217J 85*150*49	32936 180*250*45	32936 180*250*45

Table 2 – Oil Seals for SMR “Original” series Shaft Mount Reducers (all SMR oil seals are TC double lip oil seals).


Model Number	Input Shaft (1 Required)			Output Shaft (2 Required)		
	Housing Diameter	Shaft Diameter	Width	Housing Diameter	Shaft Diameter	Width
SMR2	62	30	8	100	65	10
SMR3	57.2	32	10	92.25	73.03	9.53
SMR4	55	38	8	120	80	10
SMR5	75	50	10	120	95	10
SMR6	95	60	10	160	110	12
SMR7	95	60	10	160	120	13
SMR8	100	65	10	170	140	12
SMR9	100	65	10	190	165	13
SMR10	90	70	10	210	180	15

All dimensions on this page are in millimeters (mm).



Motor Mount Installation

WARNING: To ensure that the drive is not unexpectedly started, turn off and lock out tag the power source before proceeding. Failure to observe these precautions could result in bodily harm or death.



Note: Refer to photo for positions of all parts before installation.

1. Remove the two or three bolts required for mounting the motor mount from the reducer housing. Install the front and rear supports (2) using the new reducer bolts (1) supplied with the motor mount. Make sure support flanges face output side of reducer. Tighten bolts securely.
2. Mount bottom plate (3) on supports with bolts supplied. Insert bolts (7) from top through slotted holes. Add flat washer, lock washer, and nut. Hand tighten.
3. Thread two nuts (6) on each threaded stud (5) leaving approximately 1" of stud protruding at one end. Insert threaded stud with 1" of threads through corner hole of bottom plate. Thread a hex nut (6) on the studs and tighten securely.
4. Slide top plate (4) over the threaded stud, making sure the center handling hole is positioned opposite input side of reducer. Thread a hex nut (6) on the studs and tighten securely.
5. Locate the proper position for the motor and bolt it to the top plate. Tighten bolts securely.
6. Install motor sheave and reducer sheave as close to motor and reducer housings as possible. Accurately align the motor and reducer sheave by sliding bottom plate in relation to supports. Tighten bolts (7) securely.
7. Install V-belts and tension belts by alternately adjusting nut (6) on the threaded studs (jackscrews). Make certain that all bolts are securely tightened, the V- belt drive is properly aligned and an appropriate belt guard is installed before operating the drive.

Backstop Installation

WARNING: Failure to install a backstop assembly correctly can result in injury to personnel and/or destruction of the backstop assembly, the speed reducer and other property. Read all backstop installation instructions completely before installing a backstop assembly. Certain size speed reducers require the installation of a circlip (snap ring) on the input shaft for the purposes of keeping the backstop assembly from moving in an axial direction on the input shaft during speed reducer operation. Failure to install this circlip (snap ring) may result in backstop failure and can destroy the speed reducer.

WARNING TO ELECTRICIANS: Before powering up equipment that contains a shaft mount reducer containing an installed backstop assembly, disconnect the v-belts from the motor sheave and confirm the rotation direction of the motor. Applying power to the motor in a reverse direction against the free wheel direction of the backstop assembly will destroy the backstop assembly and possibly destroy the shaft mount reducer as well. Failure to comply with this instruction will void the manufacturer's warranty of the speed reducer and the backstop assembly and may result in injury to personnel or property.

WARNING: Use only WorldWide Electric Corporation *SMR#BSK* style backstop assemblies in the "Original" series shaft mount reducers. Do not use any other brand or style of backstop assemblies in these speed reducers. Using other brands or styles of backstop assemblies may result in backstop assembly failure and may result in injury to personnel or property. Using another manufacturer or style of backstop assembly in the "Original" series shaft mount reducer will void the manufacturer's warranty of the speed reducer and the backstop assembly.

CAUTION: To avoid premature failure of the backstop or possible machine malfunction, installation of the backstop should be carried out by suitably qualified personnel and according to the following instructions:

Backstop Description


1. The main components of SMR#BSK units are: Inner race (if applicable), outer race, a number of energized sprags and side plate.
2. The maximum permissible overrunning speed must not be exceeded.
3. When used in dual drive applications, the maximum driving speed must not be exceeded.
4. Backstops (cam clutches) are shaft mounted, so the shaft on which the clutch is mounted must be hardened to HRC 56-60 and 1.5 mm case depth after grinding. Grind to 1.5S (16 micro-inch) finish. The taper of this shaft should not exceed 0.01 mm per 50 mm.

Prior to Installation

1. The units should be unpacked and installed in a clean dry working environment.
2. For units dispatched 'dry', corrosion inhibitor should be removed using flushing oil prior to installation.
3. The inner race should be fitted to a shaft of (-0.01mm to -0.025mm) tolerance if the unit is supplied with a metric bore. Details for each type are shown in the dimensions tables on pages 13-14.
4. The mounting register for the outer race should be within the housing bore (0mm to +0.03mm) tolerance. Details for each type are shown in the dimensions tables on pages 13-14.
5. The freewheeling direction should be checked prior to installation (see Backstop Assembly Type and Rotation Illustration below).
6. If reversal of the freewheeling direction is required, turn the backstop through 180 degrees.

Installation

1. The backstop (clutch) should be installed as an assembly. For backstops with an inner and outer race way, do not separate the two parts.
2. The inner race should be pulled on to the shaft. The key should be the full length of the hub.
3. For installation of the backstop, mount the backstop with bearings at both sides or on one side in order to obtain concentricity between the shaft and the backstop outer race and to take up radial or thrust loads which may work on the outer race or the shaft. (See Mounting Example below).



Mounting Example

4. The backstop should be mounted on the shaft by rotating it in the direction marked by the arrow shown on the clutch plate. Do not apply shock to the backstop by hammering. The backstop may be tapped gently if necessary with a soft hammer (rawhide, not a lead hammer).
5. On SMR reducers sizes 6 (SMR6) and 7 (SMR7), to prevent axial movement of the SMR6/7BSK after installation, a circlip (snap ring) must be placed onto the SMR backstop mounting shaft. A small groove is located on the backstop mounting shaft for insertion of the circlip. This groove is easily seen on the SMR backstop mounting shaft after removal of the backstop cover. The SMR6/7BSK uses a 38*1.5 circlip. Circlip rings are provided with each SMR6/7BSK. Take care not to accidentally discard them when opening the SMR6/7BSK packaging.
6. On SMR reducers sizes 8 (SMR8), 9 (SMR9), and 10 (SMR10), to prevent axial movement of the SMR8/9BSK or SMR10BSK after installation, a circlip (snap ring) must be placed onto the SMR backstop mounting shaft. A small groove is located on the backstop mounting shaft for insertion of the circlip. This groove is easily seen on the SMR backstop mounting shaft after removal of the backstop cover. The SMR8/9BSK and SMR10BSK uses a 45*1.5 circlip. Circlip rings are provided with each SMR8/9BSK and SMR10BSK. Take care not to accidentally discard them when opening the SMR8/9BSK or SMR10BSK packaging.
7. The backstops (clutches) have the same outside diameters as the bearings. Bore tolerance of the housing in which the backstop is assembled should be within the range of each type of SMR#BSK.
8. Concentricity of the housing bore and shaft should be within 0.05 mm.

After Installation

1. After installation, ensure smooth rotation of the units in the freewheeling direction by manually turning the input shaft of the reducer to confirm the desired direction of rotation.
2. Ensure the unit contains the correct volume of the lubricant prior to use.
3. The expected drag torque produced when freewheeling is about 1/1000 of the nominal torque.

Dismantling

1. To dismantle the units, please follow the Installation section in reverse sequence.

Lubrication and Maintenance of the Backstop Assembly


1. Type SMR#BSK backstops are factory lubricated with oil.
2. The work temperature is between minus 20 degrees Celsius to plus 70 degrees Celsius.
3. The backstop can operate without maintenance.
4. If arduous conditions exist (i.e. high temperature/dusty conditions), the backstop should be re-lubricated every 3 to 6 months.
5. Do not use slip additives such as graphite, Molykote or similar agents in the oil and grease as they will shorten service life of the clutches.

Backstop Assembly Type and Rotation Illustration




Type 1 -
Backstop
assembly
without
Inner Race

Type 2 -
Backstop
assembly
with Inner
Race




Type 1 – Backstop Assembly
(without Inner Race)



Type 2 – Backstop Assembly
(with Inner Race)


SMR (2,3,4,5) BSK Backstops – Dimensions

Model#	Out Race A inches (mm)	Housing Bore (mm)	Inner Race B inches (mm)	Shaft (mm)	Width E inches (mm)
SMR2BSK	2.44 (62 ⁺⁰ _{-0.03})	62 ^{+0.03} ₊₀	0.97 (24.65)	24.65 ^{-0.01} _{-0.025}	0.87 (22)
SMR3BSK	1.85 (47 ⁺⁰ _{-0.025})	47 ^{+0.025} ₊₀	0.74 (18.796)	18.796 ^{-0.01} _{-0.025}	0.98 (25)
SMR4BSK	2.44 (62 ⁺⁰ _{-0.03})	62 ^{+0.03} ₊₀	0.89 (22.57)	2.57 ^{-0.01} _{-0.025}	0.91 (23)
SMR5BSK	3.15 (80 ⁺⁰ _{-0.03})	80 ^{+0.03} ₊₀	1.22 (30.862)	30.862 ^{-0.01} _{-0.025}	1.26 (32)



SMR (6/7,8/9,10/12) BSK Backstops – Dimensions

Model#	Out Race A inches (mm)	Housing Bore (mm)	Inner Race B inches (mm)	Inner Race B Tolerance (mm)	Width E inches (mm)
SMR6/7BSK	3.94 (100 ⁺⁰ _{-0.035})	100 ^{+0.035} ₊₀	1.50 (38.1)	38.1 ^{-0.01} _{-0.035}	1.16 (29.5)
SMR8/9BSK	4.5 (114.3 ⁺⁰ _{-0.035})	114.3 ^{+0.035} ₊₀	1.75 (44.45)	44.45 ^{-0.01} _{-0.035}	1.06 (27)
SMR10/12BSK	4.5 (114.3 ⁺⁰ _{-0.035})	114.3 ^{+0.035} ₊₀	1.75 (44.45)	44.45 ^{-0.01} _{-0.035}	1.575 (40)



Guidelines for Long-term Storage

Guidelines for Long-term Storage:

During periods of long storage, or when waiting for delivery or installation of other equipment, special care should be taken to protect a gear reducer to have it ready to be in the best condition when placed into service. By taking special precautions, problems such as seal leakage and reducer failure due to lack of lubrication, improper lubrication quality, or contamination can be avoided. The following precautions will protect gear reducers during periods of extended storage.

Preparation:

1. Drain the oil from the unit. Add a vapor phase corrosion inhibiting oil in accordance with followed table:

Table - Quantities of Vapor Phase Oil


Size	2	3	4	5	6	7	8	9
Liters	.1	.1	.2	.3	.4	.5	.6	.9

2. Seal the unit airtight. Replace the air breather plug with a standard pipe plug and wire the vent to the unit.
3. Cover the shaft extension with a waxy rust preventative compound that will keep oxygen away from the bare metal.
4. The instruction manuals and lubrication tags are paper and must be kept dry. Either remove these documents and store them inside or cover the unit with a durable waterproof cover which can keep moisture away.
5. Protect reducer from dust, moisture, and other contaminants by storing the unit in a dry area.
6. In damp environments, the reducer should be packed inside a moisture- proof container or an envelope of polyethylene containing a desiccant material. If the reducer is to be stored outdoors, cover the entire exterior with a rust preventative.

When Placing the Reducer into Service:

1. Assemble the vent plug into the proper hole.
2. Clean the shaft extensions with petroleum solvents.
3. Fill the unit to the proper oil level using a recommended lubricant. The vapor phase corrosion inhibiting oil will not affect the new lubricant.
4. Follow the installation instructions provided in this manual.

SMR Exploded View



No.	Part Name
1	Right hand gear case
2	Output hub bearing
3	Output hub
4	2nd reduction gear key
5	1st reduction gear key
6	Intermediate pinion
7	2nd reduction gear
8	Oil pipe plug
9	Left hand gear case
10	Breather plug
11	Output hub bearing cover gasket
12	Output hub bearing cover
13	Output hub oil seal
14	Cover lock washer
15	Cover bolt
16	Case bolt
17	Hollow dowel
18	Output hub collar
19	Output hub circlip
20	Case plain washer
21	Lifting eye

No.	Part Name
22	Input shaft oil seal
23	Input shaft bearing cover
24	Bearing cover gasket
25	Intermediate bearing cover
26	Bearing cover gasket
27	Intermediate pinion bearing (input side)
28	Input shaft bearing (input side)
29	Input shaft square key
30	Input shaft & pinion
31	1st reduction gear
32	Input shaft bearing (output side)
33	Intermediate pinion bearing (output side)
34	Backstop cover gasket
35	Backstop cover
36	Intermediate cover gasket
37	Intermediate pinion cover
38	Cross recessed screw
39	Case nut
40	Case lock washer
41	Adaptor for torque arm (not shown)
42	Torque arm (not shown)

SMR Ratio/ Speed Table

SMR "Original" series Shaft Mount Reducers - Actual Ratio and Maximum Input Speed (RPM).

Model Number	Nominal Ratio 15:1		Nominal Ratio 25:1	
	Actual Ratio	Maximum Input Speed	Actual Ratio	Maximum Input Speed
SMR2	14.04	1974	23.37	1994
SMR3	14.87	2083	24.75	2100
SMR4	15.13	2118	24.38	2072
SMR5	15.4	1925	25.56	2044
SMR6	15.34	1916	25.14	2010
SMR7	15.23	1827	24.84	1844
SMR8	15.08	1809	24.62	1847
SMR9	15.12	1814	25.66	1925
SMR10	15.42	1819	24.44	1823

Limited Warranty

Limited Warranty:

WorldWide Electric Corporation (The Company) warrants its products to be free from defect in materials or workmanship to the original purchaser for a period of two (2) years from the date of sale (invoice). For this warranty to be effective, this product must be installed, used and maintained by the original purchaser in the accordance with good industry standards. The warranty does not cover normal wear, tear and erosion from use, misuse, abuse or corrosion.

In the event of failure, it shall be the responsibility of the original purchaser to notify The Company either in writing or by telephone to make arrangements for the correction of the problem. The purchaser shall be responsible for transportation charges connected with the return, exchange or repair of parts. Returns found defective upon inspection by our warranty department or authorized warranty service agent will be replaced free of charge.

The Company shall not be liable for any labor cost connected with the replacement of the equipment, the replacement of the parts or adjustments to the equipment by the purchaser or their contractor without The Company's prior written approval.

The Company, as the exclusive remedy under this warranty, shall at it's option, repair or replace defective items or, if agreed upon, refund the purchase price less reasonable allowance for depreciation in exchange for product.

THE COMPANY MAKES NO OTHER WARRANTIES AND ALL IMPLIED OR EXPRESSED WARRANTIES AND REPRESENTATIONS, EXCEPT THAT OF TITLE, ARE DISCLAIMED. ALL IMPLIED WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE BUT NOT LIMITED TO JUST THOSE THAT ARE DISCLAIMED. LIABILITY FOR CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES AND LOSSES UNDER ANY AND ALL WARRANTIES WHETHER IN CONTACT, TORT OR OTHERWISE ARE EXCLUDED TO THE EXTENT EXCLUSION IS PERMITTED BY LAW.

